

Signalink™ USB Product Guide

This document can be used to find the Signalink USB, Radio Cable, and Jumper Module part number that is needed for a given radio. You can search this document for your radio model using your viewer's "Find" feature (CTRL-F), or simply scroll down to browse. Radios are organized alphabetically by manufacturer and listed in alpha-numeric order. If your radio isn't listed, then please contact us and we will confirm the part numbers that are needed.

Every effort has been made to insure that the information provided in this document is accurate. However, mistakes do sometimes happen, and it is simply not possible for us to be aware of the idiosyncrasies of every available radio. If you have any doubts or questions about the information provided here, or if you're not sure which part numbers you need for your radio, then please contact us before ordering.

Please note the following when selecting the part numbers for your radio:

- The Signalink USB is always supplied with one radio cable. The Signalink USB part number (SLUSBxxx) determines which radio cable is included. For example, Signalink USB p/n "SLUSB6PM" includes radio cable p/n "SLCAB6PM". If you have multiple radios and need more than one radio cable, then extra radio cables can be purchased using the part numbers shown under the "Radio Cable Only" column.
- Some radios have multiple options for connecting the Signalink USB. Rear panel connections are generally preferred over the Mic jack and will be listed first when available.
- If the Signalink USB or Radio Cable part number is noted as "DATA", "ACCY", "ACC", "REAR" (etc.), then the part number is for the radio's rear panel connection. If the part number is not marked this way then it is for the radio's Mic jack.
- Our optional Plug & Play Jumper Modules provide the easiest installation possible and are highly recommended for configuring your Signalink. Jumper modules are available for most configurations and are shown under the "Jumper Module" column. If a jumper module is not listed then you will need to configure the Signalink using the supplied jumper wires.
- Be sure to read any notes shown for your radio as these detail important radio requirements or restrictions.

ADI

Radio	Signalink USB	Radio Cable Only	Jumper Module
AR-146	SLUSB8R	SLCAB8R	
AR-147	SLUSB8R	SLCAB8R	
AR-446	SLUSB8R	SLCAB8R	

ALINCO

Radio	Signalink USB	Radio Cable Only	Jumper Module
ALD-24T	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-22HT	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-22T	SLUSB8R	SLCAB8R	SLMOD8RK
ALR-72T	SLUSB8R	SLCAB8R	SLMOD8RK
DJ-47E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-47T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-G7T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-S17	SLUSBVXY	SLCABVXY	SLMODHT
DJ-S47E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V17	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V27T	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V57E	SLUSBVXY	SLCABVXY	SLMODHT
DJ-V57T	SLUSBVXY	SLCABVXY	SLMODHT
DR-03T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-06T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-110T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-112T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-130T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-135LH	SLUSB8R	SLCAB8R	SLMOD8RK
DR-150	SLUSB8R	SLCAB8R	SLMOD8RK
DR-235T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-430T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-435T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-510T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-570T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-590T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-592T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-599T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-600T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-605E	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-605T	SLUSBRJ4	SLCABRJ4	SLMODR4I

ALINCO (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
DR-610E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-610T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-620E	SLUSB8R	SLCAB8R	SLMOD8RK
DR-620T	SLUSB8R	SLCAB8R	SLMOD8RK
DR-635	SLUSB8R	SLCAB8R	SLMOD8RK
DR-638HE	SLUSB8R	SLCAB8R	SLMOD8RK
DR-735E	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-735T	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4I
DR-1200	SLUSB8R	SLCAB8R	SLMOD8RK
DR-M03R	SLUSB8R	SLCAB8R	SLMOD8RK
DR-M06R	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70EH	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70T	SLUSB8R	SLCAB8R	SLMOD8RK
DX-70TH	SLUSB8R	SLCAB8R	SLMOD8RK
DX-77	SLUSB8R	SLCAB8R	SLMOD8RK
DX-SR8T	SLUSB8R	SLCAB8R	SLMOD8RK
DX-SR8E	SLUSB8R	SLCAB8R	SLMOD8RK
DX-SR9	SLUSB8R	SLCAB8R	SLMOD8RK

ANYTONE

Radio	Signalink USB	Radio Cable Only	Jumper Module
AT-D868UV	SLUSBHTW	SLCABHTW	SLMOD6PM

AZDEN

Radio	Signalink USB	Radio Cable Only	Jumper Module
PCS 5000	SLUSB8R	SLCAB8R	
PCS 6000	SLUSB8R	SLCAB8R	
PCS 7000	SLUSB8R	SLCAB8R	

BAOFENG / BTECH

Radio	Signalink USB	Radio Cable Only	Jumper Module
BF-320	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-490	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-520	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-530	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-568	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-658	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-758A	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-758S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-666S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-777	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-777S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-888S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-999	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-999S	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8+	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F8HP	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-F9V2	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V6	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V7	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V8	SLUSBHTW	SLCABHTW	SLMOD6PM
BF-V85	SLUSBHTW	SLCABHTW	SLMOD6PM
C-150	SLUSBHTW	SLCABHTW	SLMOD6PM
GMRS-V1	SLUSBHTW	SLCABHTW	SLMOD6PM
GT-3	SLUSBHTW	SLCABHTW	SLMOD6PM
MURS-V1	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-3	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-3R+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5R	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RA	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RB	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RC	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RD	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RE	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-5RE+	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-8	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-8D	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-B5	SLUSBHTW	SLCABHTW	SLMOD6PM
UV-25x2	SLUSBHTY	SLCABHTY	
UV-25x4	SLUSBHTY	SLCABHTY	
UV-50x2	SLUSBHTY	SLCABHTY	
UV-82	SLUSBHTW	SLCABHTW	SLMOD6PM

BRIDGECOM

Radio	SignalLink USB	Radio Cable Only	Jumper Module
BCH-220	SLUSBHTW	SLCABHTW	SLMOD6PM
BCH-270	SLUSBHTW	SLCABHTW	SLMOD6PM
BCH-700	SLUSBHTW	SLCABHTW	SLMOD6PM
BCM-144	SLUSBRJ4	SLCABRJ4	
BCM-220	SLUSBRJ4	SLCABRJ4	
BCM-440	SLUSBRJ4	SLCABRJ4	
D-30	SLUSBHTW	SLCABHTW	SLMOD6PM
D-500	SLUSBHTW	SLCABHTW	SLMOD6PM

CONNECT SYSTEMS

Radio	SignalLink USB	Radio Cable Only	Jumper Module
CS-108G	SLUSB6PM (ACC)	SLCAB6PM (ACC)	

DRAKE

Radio	SignalLink USB	Radio Cable Only	Jumper Module
TR-7	SLUSB4R	SLCAB4R	
TR-22	SLUSB4R	SLCAB4R	
TR-33	SLUSB4R	SLCAB4R	
UV-3	SLUSB4R	SLCAB4R	

ELECRAFT

Radio	SignalLink USB	Radio Cable Only	Jumper Module
K2	SLUSB8R	SLCAB8R	SLMOD8RK
K3	SLUSBK3 (REAR)	SLCABK3 (REAR)	SLMODK3
	SLUSB8R	SLCAB8R	SLMOD8RK
K3/0-Mini	SLUSB8R	SLCAB8R	SLMOD8RK
K3/S	SLUSBK3 (REAR)	SLCABK3 (REAR)	SLMODK3
	SLUSB8R	SLCAB8R	SLMOD8RK
KX2	SLUSBKX3	SLCABKX3	SLMODKX3
KX3	SLUSBKX3	SLCABKX3	SLMODKX3

FLEX-RADIO

Radio	Signalink USB	Radio Cable Only	Jumper Module
FLEX-1500	SLUSB RJ4	SLCAB RJ4	
FLEX-3000	SLUSB RJ4	SLCAB RJ4	
FLEX-5000	SLUSB 8R	SLCAB 8R	

ICOM

Radio	Signalink USB	Radio Cable Only	Jumper Module
IC-22	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-202	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-215	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-245	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-280	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-402	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-502	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-551	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-701	SLUSB 4R	SLCAB 4R	SLMOD 4RI
IC-22U	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-25	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-27	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-28	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-37A	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-38A	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-375	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-45	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-47	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-48	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-78	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-207H	SLUSB 6PM (DATA)	SLCAB 6PM (DATA)	SLMOD 6PM
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-208H	SLUSB 6PM (DATA)	SLCAB 6PM (DATA)	SLMOD 6PM
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-228	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-229	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-251A	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-251E	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-255	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-260	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-271	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-275A	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-281A	SLUSB RJ4	SLCAB RJ4	SLMOD R4I

ICOM (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
IC-281E	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-281H	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-290	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-471	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-475	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-490	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-505	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-551	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-560	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-575A	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-575H	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-703	SLUSB 6PM (DATA)	SLCAB 6PM (DATA)	SLMOD 6PM
	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-706	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-706MKII	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-706MKIIG	SLUSB 6PM (DATA)	SLCAB 6PM (DATA)	SLMOD 6PM
	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-707	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-718	SLUSB 13I (ACCY)	SLCAB 13I (ACCY)	SLMOD 13I
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-720	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-725	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-726	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-728	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-729	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-730	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-735	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-736	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-737	SLUSB 8PD (ACCY)	SLCAB 8PD (ACCY)	SLMOD 8PD
	SLUSB 8R	SLCAB 8R	SLMOD 8RI

ICOM (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
IC-738	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-740	SLUSB8R	SLCAB8R	SLMOD8RI
IC-745	SLUSB8R	SLCAB8R	SLMOD8RI
IC-746	SLUSB8PD (ACCY) ²	SLCAB8PD (ACCY) ²	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-746PRO	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8PD (ACCY) ²	SLCAB8PD (ACCY) ²	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-751	SLUSB8R	SLCAB8R	SLMOD8RI
IC-756	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-756PRO	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-756PROII	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-756PROIII	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-761	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-765	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-775	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-775DSP	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-781	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-820H	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-821H	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-901	SLUSB8R	SLCAB8R	SLMOD8RI
IC-910H	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-970 ^{**}	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
	SLUSB8R	SLCAB8R	SLMOD8RI
IC-1201	SLUSB8R	SLCAB8R	SLMOD8RI
IC-1271	SLUSB8R	SLCAB8R	SLMOD8RI
IC-1275	SLUSB8R	SLCAB8R	SLMOD8RI
IC-2000	SLUSBRJ4	SLCABRJ4	SLMODR4I

***The 13-pin Accy Port on the IC-970 uses a non-standard pin-out and CANNOT be used with our SLCAB13I Accy Port cable.*

ICOM (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
IC-2100H	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2200H	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2300H	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2400	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-2500	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-2700	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2720H	SLUSB 6PM (DATA) SLUSB RJ4	SLCAB 6PM (DATA) SLCAB RJ4	SLMOD 6PM SLMOD R4I
IC-2730A	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2730E	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-2800	SLUSB 6PM (DATA) ¹ SLUSB RJ4	SLCAB 6PM (DATA) ¹ SLCAB RJ4	SLMOD 6PM SLMOD R4I
IC-2820	SLUSB 6PM (DATA) SLUSB RJ4	SLCAB 6PM (DATA) SLCAB RJ4	SLMOD 6PM SLMOD R4I
IC-3200	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-3210	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-3220	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-3230	SLUSB 8R	SLCAB 8R	SLMOD 8RI
IC-7000	SLUSB 6PM (DATA) SLUSB 13I (ACCY) ¹ SLUSB RJ4	SLCAB 6PM (DATA) SLCAB 13I (ACCY) ¹ SLCAB RJ4	SLMOD 6PM SLMOD 13I SLMOD R4I
IC-7100	SLUSB 6PM (DATA) SLUSB 13I (ACCY) ¹ SLUSB RJ4	SLCAB 6PM (DATA) SLCAB 13I (ACCY) ¹ SLCAB RJ4	SLMOD 6PM SLMOD 13I SLMOD R4I
IC-7200	SLUSB 13I (ACCY) ¹ SLUSB 8R	SLCAB 13I (ACCY) ¹ SLCAB 8R	SLMOD 13I SLMOD 8RI
IC-7300	SLUSB 13I (ACCY) ¹ SLUSB 8R	SLCAB 13I (ACCY) ¹ SLCAB 8R	SLMOD 13I SLMOD 8RI
IC-7400	SLUSB 6PM (DATA) SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 6PM (DATA) SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 6PM SLMOD 8PD SLMOD 8RI
IC-7410	SLUSB 13I (ACCY) SLUSB 8R	SLCAB 13I (ACCY) SLCAB 8R	SLMOD 13I SLMOD 8RI
IC-7600	SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 8PD SLMOD 8RI
IC-7610	SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 8PD SLMOD 8RI
IC-7700	SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 8PD SLMOD 8RI
IC-7800	SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 8PD SLMOD 8RI
IC-9100	SLUSB 6PM (DATA) SLUSB 13I (ACCY) ¹ SLUSB 8R	SLCAB 6PM (DATA) SLCAB 13I (ACCY) ¹ SLCAB 8R	SLMOD 6PM SLMOD 13I SLMOD 8RI
IC-9700	SLUSB 8PD (ACCY) SLUSB 8R	SLCAB 8PD (ACCY) SLCAB 8R	SLMOD 8PD SLMOD 8RI

ICOM (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
IC-F121	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
IC-M600	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M700PRO	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M710	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-M802	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD8PD
IC-V8000	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-800H	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-880	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-4100A	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-4100E	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-5100A	SLUSB RJ4	SLCAB RJ4	SLMOD R4I
ID-5100E	SLUSB RJ4	SLCAB RJ4	SLMOD R4I

JRC

Radio	Signalink USB	Radio Cable Only	Jumper Module
JST-135	SLUSB8R	SLCAB8R	
JST-145	SLUSB8R	SLCAB8R	
JST-245	SLUSB8R	SLCAB8R	

KENWOOD

Radio	Signalink USB	Radio Cable Only	Jumper Module
TH-D7	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7AG	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D7E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D72E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-D74E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F6	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F6A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F7	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-F7E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-G71	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-G71A	SLUSBHTW	SLCABHTW	SLMOD6PM

KENWOOD (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
TH-G71E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2AT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2E	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-K2ET	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21BT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-21T	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22A	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22AT	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-22E	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-90	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-240	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-250	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-255	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-260	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-260G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-270	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-270G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-272G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-278	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-278G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-340	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-349	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-350	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-353	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-360	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-360G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-370	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-370G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-373G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-378	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-378G	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-430	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-431	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-715	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-863G	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-2100	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2102	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2107	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2118	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-2160	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3100	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3101	SLUSBHTW	SLCABHTW	SLMOD6PM

KENWOOD (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
TK-3102	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3107	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3118	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-3160	SLUSBHTW	SLCABHTW	SLMOD6PM
TK-7102H	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7108HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7108M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7160M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7162E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7180E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-7189E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8108HM	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8108M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8160E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8160M	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8162E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8180E	SLUSBRJ4	SLCABRJ4	SLMODR4K
TK-8189	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-201	SLUSB8R	SLCAB8R	SLMOD8RK
TM-211	SLUSB8R	SLCAB8R	SLMOD8RK
TM-221	SLUSB8R	SLCAB8R	SLMOD8RK
TM-231	SLUSB8R	SLCAB8R	SLMOD8RK
TM-241	SLUSB8R	SLCAB8R	SLMOD8RK
TM-251	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-255	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-261	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-271**	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-271A**	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-281	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-321	SLUSB8R	SLCAB8R	SLMOD8RK
TM-331	SLUSB8R	SLCAB8R	SLMOD8RK
TM-401	SLUSB8R	SLCAB8R	SLMOD8RK
TM-421	SLUSB8R	SLCAB8R	SLMOD8RK
TM-431	SLUSB8R	SLCAB8R	SLMOD8RK

**European models only. All other TM-271 / TM-271A models must use the RJ-45 Mic jack.

KENWOOD (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
TM-441	SLUSB8R	SLCAB8R	SLMOD8RK
TM-451	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-455	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-461	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-481A	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-521	SLUSB8R	SLCAB8R	SLMOD8RK
TM-531	SLUSB8R	SLCAB8R	SLMOD8RK
TM-541	SLUSB8R	SLCAB8R	SLMOD8RK
TM-621	SLUSB8R	SLCAB8R	SLMOD8RK
TM-631	SLUSB8R	SLCAB8R	SLMOD8RK
TM-641	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-642	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-701	SLUSB8R	SLCAB8R	SLMOD8RK
TM-721	SLUSB8R	SLCAB8R	SLMOD8RK
TM-731	SLUSB8R	SLCAB8R	SLMOD8RK
TM-732	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-733A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-741	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-742	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-941	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-942	SLUSBRJ4	SLCABRJ4	SLMODR4K
TM-2530	SLUSB8R	SLCAB8R	SLMOD8RK
TM-2550	SLUSB8R	SLCAB8R	SLMOD8RK
TM-2570	SLUSB8R	SLCAB8R	SLMOD8RK
TM-3530	SLUSB8R	SLCAB8R	SLMOD8RK
TM-D700	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D700A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710E	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710G	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-D710GA	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-G707	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V7A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K

KENWOOD (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
TM-V71A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V71E	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TM-V708	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TR-50	SLUSB8R	SLCAB8R	SLMOD8RK
TR-751	SLUSB8R	SLCAB8R	SLMOD8RK
TR-851	SLUSB8R	SLCAB8R	SLMOD8RK
TR-7200A	SLUSB4R	SLCAB4R	SLMOD4RK
TR-7400A	SLUSB4R	SLCAB4R	SLMOD4RK
TR-7500	SLUSB4R	SLCAB4R	SLMOD4RK
TS-50	SLUSB8R	SLCAB8R	SLMOD8RK
TS-60	SLUSB8R	SLCAB8R	SLMOD8RK
TS-120S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-130S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-130SE	SLUSB4R	SLCAB4R	SLMOD4RK
TS-140S	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-180S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-430	SLUSB8R	SLCAB8R	SLMOD8RK
TS-440	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-440SAT	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-450	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-480HX	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TS-480SAT	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4K
TS-511S	SLUSB4R	SLCAB4R	SLMOD4RK
TS-520	SLUSB4R	SLCAB4R	SLMOD4RK
TS-530	SLUSB4R	SLCAB4R	SLMOD4RK
TS-570	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-570D	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-570DG	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-570S	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-570SG	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK

KENWOOD (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
TS-590S	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-590SG	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-600	SLUSB4R	SLCAB4R	SLMOD4RK
TS-660	SLUSB8R	SLCAB8R	SLMOD8RK
TS-670	SLUSB8R	SLCAB8R	SLMOD8RK
TS-680S	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-690	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-700	SLUSB4R	SLCAB4R	SLMOD4RK
TS-701	SLUSB8R	SLCAB8R	SLMOD8RK
TS-711	SLUSB8R	SLCAB8R	SLMOD8RK
TS-780	SLUSB8R	SLCAB8R	SLMOD8RK
TS-790	SLUSB8R	SLCAB8R	SLMOD8RK
TS-811	SLUSB8R	SLCAB8R	SLMOD8RK
TS-820	SLUSB4R	SLCAB4R	SLMOD4RK
TS-830	SLUSB4R	SLCAB4R	SLMOD4RK
TS-850	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-870	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-930	SLUSB8R	SLCAB8R	SLMOD8RK
TS-940	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-950	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-990	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-2000	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TS-2000X	SLUSB13K (ACCY) SLUSB8R	SLCAB13K (ACCY) SLCAB8R	SLMOD13K SLMOD8RK
TW-4000	SLUSB8R	SLCAB8R	SLMOD8RK
TW-4100	SLUSB8R	SLCAB8R	SLMOD8RK

MIDLAND

Radio	Signalink USB	Radio Cable Only	Jumper Module
13-510	SLUSB4R	SLCAB4R	

MOTOROLA

Radio	Signalink USB	Radio Cable Only	Jumper Module
CM200	SLUSBRJ4	SLCABRJ4	
CM300	SLUSBRJ4	SLCABRJ4	
GM300	SLUSBRJ4	SLCABRJ4	

PUXING

Radio	Signalink USB	Radio Cable Only	Jumper Module
PX-328	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-333	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-666	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-777	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-888	SLUSBHTW	SLCABHTW	SLMOD6PM
PX-888K	SLUSBHTW	SLCABHTW	SLMOD6PM

RADIO SHACK

Radio	Signalink USB	Radio Cable Only	Jumper Module
HTX-100	SLUSB8R	SLCAB8R	
HTX-212	SLUSBRJ4	SLCABRJ4	
HTX-242	SLUSBRJ4	SLCABRJ4	

RETEVIS

Radio	Signalink USB	Radio Cable Only	Jumper Module
RT2	SLUSBHTW	SLCABHTW	SLMOD6PM
RT3	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5R	SLUSBHTW	SLCABHTW	SLMOD6PM
RT5RV	SLUSBHTW	SLCABHTW	SLMOD6PM
RT8	SLUSBHTW	SLCABHTW	SLMOD6PM
RT23	SLUSBHTW	SLCABHTW	SLMOD6PM
RT82	SLUSBHTW	SLCABHTW	SLMOD6PM

SGC

Radio	Signalink USB	Radio Cable Only	Jumper Module
SGC-2000	SLUSB4R	SLCAB4R	
SGC-2020	SLUSB8R	SLCAB8R	SLMOD8RK

TEN-TEC

Radio	Signalink USB	Radio Cable Only	Jumper Module
Argonaut V	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB4R	SLCAB4R	SLMOD4RT
Argonaut VI	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
Corsair 561	SLUSB4R	SLCAB4R	SLMOD4RT
Delta II	SLUSB4R	SLCAB4R	SLMOD4RT
Eagle	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
Jupiter	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB4R	SLCAB4R	SLMOD4RT
Omni VI	SLUSB4R	SLCAB4R	SLMOD4RT
Omni VII	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
Orion	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD5PD
	SLUSB4R	SLCAB4R	SLMOD4RT
Orion II	SLUSB8PD (ACCY)	SLCAB8PD (ACCY)	SLMOD5PD
	SLUSB8R	SLCAB8R	SLMOD8RY
Pegasus	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
	SLUSB4R	SLCAB4R	SLMOD4RT
Scout	SLUSB4R	SLCAB4R	SLMOD4RT

TYT

Radio	Signalink USB	Radio Cable Only	Jumper Module
DM-380	SLUSBHTW	SLCABHTW	SLMOD6PM
DM-390	SLUSBHTW	SLCABHTW	SLMOD6PM
TH-9000D	SLUSBRJ4	SLCABRJ4	
TH-9800	SLUSBRJ1	SLCABRJ1	SLMODR1Y

WOXUN

Radio	Signalink USB	Radio Cable Only	Jumper Module
KG-UVD1P	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV3D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV3X	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV6D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV6X	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-UV8D	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-659	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-669	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-669+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-679	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-679+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-816	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-819	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-689	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-689+	SLUSBHTW	SLCABHTW	SLMOD6PM
KG-699	SLUSBHTW	SLCABHTW	SLMOD6PM

XIEGU

Radio	Signalink USB	Radio Cable Only	Jumper Module
G90	SLUSB8PM (ACC)	SLCAB8PM (ACC)	SLMOD6PM
X-1M	SLUSB847	SLCAB847	
X-1MPRO	SLUSB847	SLCAB847	
X-108G	SLUSB6PM (ACC)	SLCAB6PM (ACC)	
X-5105	SLUSB8PM (ACC)	SLCAB8PM (ACC)	SLMOD6PM

YAESU

Radio	Signalink USB	Radio Cable Only	Jumper Module
FT-1	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-1D	SLUSBHTY	SLCABHTY	SLMODHT
FT-2DR	SLUSBHTY	SLCABHTY	SLMODHT
FT-7B	SLUSB4R	SLCAB4R	SLMOD4RY
FT-50	SLUSBHTY	SLCABHTY	SLMODHT
FT-60	SLUSBHTY	SLCABHTY	SLMODHT
FT-60R	SLUSBHTY	SLCABHTY	SLMODHT
FT-70DR	SLUSBHTY	SLCABHTY	SLMODHT

YAESU (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
FT-80C	SLUSB8R	SLCAB8R	SLMOD8RY
FT-90	SLUSB RJ1	SLCAB RJ1	SLMOD R1Y
FT-90R	SLUSB RJ1	SLCAB RJ1	SLMOD R1Y
FT-100	SLUSB6PM (DATA) SLUSB RJ1	SLCAB6PM (DATA) SLCAB RJ1	SLMOD6PM
FT-100D	SLUSB6PM (DATA) SLUSB RJ1	SLCAB6PM (DATA) SLCAB RJ1	SLMOD6PM
FT-101	SLUSB4R	SLCAB4R	SLMOD4RY
FT-101ZD	SLUSB4R	SLCAB4R	SLMOD4RY
FT-102	SLUSB8R	SLCAB8R	SLMOD8RY
FT-107	SLUSB8R	SLCAB8R	SLMOD8RY
FT-107M	SLUSB8R	SLCAB8R	SLMOD8RY
FT-221	SLUSB4R	SLCAB4R	SLMOD4RY
FT-225	SLUSB4R	SLCAB4R	SLMOD4RY
FT-227R	SLUSB4R	SLCAB4R	SLMOD4RY
FT-250R	SLUSBHTY	SLCABHTY	SLMODHT
FT-270R	SLUSBVXY	SLCABVXY	SLMODHT
FT-290	SLUSB8R	SLCAB8R	SLMOD8RY
FT-301	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301D	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301S	SLUSB4R	SLCAB4R	SLMOD4RY
FT-301SD	SLUSB4R	SLCAB4R	SLMOD4RY
FT-450	SLUSB6PM (DATA) SLUSB RJ4	SLCAB6PM (DATA) SLCAB RJ4	SLMOD6PM SLMOD R4Y
FT-600	SLUSB RJ4	SLCAB RJ4	SLMOD R4Y
FT-707	SLUSB8R	SLCAB8R	SLMOD8RY
FT-726R	SLUSB8R	SLCAB8R	SLMOD8RY
FT-736	SLUSB8R	SLCAB8R	SLMOD8RY
FT-736R	SLUSB8R	SLCAB8R	SLMOD8RY
FT-747	SLUSB8R	SLCAB8R	SLMOD8RY
FT-757	SLUSB8R	SLCAB8R	SLMOD8RY
FT-757GX	SLUSB8R	SLCAB8R	SLMOD8RY
FT-767GX	SLUSB8R	SLCAB8R	SLMOD8RY
FT-817	SLUSB6PM (DATA) SLUSB RJ4	SLCAB6PM (DATA) SLCAB RJ4	SLMOD6PM SLMOD R4Y
FT-817ND	SLUSB6PM (DATA) SLUSB RJ4	SLCAB6PM (DATA) SLCAB RJ4	SLMOD6PM SLMOD R4Y
FT-840	SLUSB8R SLUSB6PM (DATA) ³	SLCAB8R SLCAB6PM (DATA) ³	SLMOD8RY SLMOD6PM
FT-847	SLUSB847 (DATA I/O) ² SLUSB8R SLUSB6PM (DATA) ³	SLCAB847 (DATA I/O) ² SLCAB8R SLCAB6PM (DATA) ³	SLMODHT SLMOD8RY SLMOD6PM
FT-857	SLUSB6PM (DATA) SLUSB RJ4	SLCAB6PM (DATA) SLCAB RJ4	SLMOD6PM SLMOD R4Y
FT-857D	SLUSB6PM (DATA) SLUSB RJ4	SLCAB6PM (DATA) SLCAB RJ4	SLMOD6PM SLMOD R4Y

YAESU (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
FT-890	SLUSB8R	SLCAB8R	SLMOD8RY
FT-891	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM
FT-897	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-897D	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-900	SLUSBRJ4	SLCABRJ4	SLMODR4Y
FT-901DM	SLUSB4R	SLCAB4R	SLMOD4RY
FT-920	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-950	SLUSB6PM (DATA) SLUSB8R	SLCAB6PM (DATA) SLCAB8R	SLMOD6PM SLMOD8RY
FT-980	SLUSB8R	SLCAB8R	SLMOD8RY
FT-990	SLUSB8R	SLCAB8R	SLMOD8RY
FT-991	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-991A	SLUSB6PM (DATA) SLUSBRJ4	SLCAB6PM (DATA) SLCABRJ4	SLMOD6PM SLMODR4Y
FT-1000	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1000D	SLUSB8R	SLCAB8R	SLMOD8RY
FT-1000MP	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1000MPMKV	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1000MPMKVF	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-1500M	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-1802	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-1900R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2000	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-2200	SLUSB8R	SLCAB8R	SLMOD8RY
FT-2400	SLUSBRJ4	SLCABRJ4	
FT-2500	SLUSBRJ4	SLCABRJ4	
FT-2600	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2800M	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2900R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-2980R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FT-5100	SLUSB8R	SLCAB8R	SLMOD8RY
FT-7100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM

YAESU (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
FT-7800R	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-7900R	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-8000	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8100	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8500	SLUSB6PM (DATA)	SLCAB6PM (DATA)	SLMOD6PM
FT-8800R	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-8900R	SLUSB6PM (DATA) SLUSBRJ1	SLCAB6PM (DATA) SLCABRJ1	SLMOD6PM SLMODR1Y
FT-DX101D	SLUSB6PM (DATA) SLUSB8R	SLCAB6PM (DATA) SLCAB8R	SLMOD6PM SLMOD8RY
FT-DX1200	SLUSB6PM (DATA) SLUSB8R	SLCAB6PM (DATA) SLCAB8R	SLMOD6PM SLMOD8RY
FT-DX3000	SLUSB6PM (DATA) SLUSB8R	SLCAB6PM (DATA) SLCAB8R	SLMOD6PM SLMOD8RY
FT-DX5000	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-DX5000D	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-DX5000MP	SLUSB5PD (ACCY) SLUSB8R	SLCAB5PD (ACCY) SLCAB8R	SLMOD5PD SLMOD8RY
FT-DX9000	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FT-DX9000D	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FT-DX9000MP	SLUSB5PD (ACCY)	SLCAB5PD (ACCY)	SLMOD5PD
FTM-100DR	SLUSB6PM (DATA) ⁴	SLCAB6PM (DATA) ⁴	SLMOD6PM
FTM-350	SLUSB6PM (DATA) ⁵ SLUSBRJ1	SLCAB6PM (DATA) ⁵ SLCABRJ1	SLMOD6PM SLMODR1Y
FTM-350R	SLUSB6PM (DATA) ⁵ SLUSBRJ1	SLCAB6PM (DATA) ⁵ SLCABRJ1	SLMOD6PM SLMODR1Y
FTM-350AR	SLUSB6PM (DATA) ⁵ SLUSBRJ1	SLCAB6PM (DATA) ⁵ SLCABRJ1	SLMOD6PM SLMODR1Y
FTM-400DR	SLUSB6PM (DATA) ⁴	SLCAB6PM (DATA) ⁴	SLMOD6PM
FTM-3100R	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-3200DR	SLUSBRJ1	SLCABRJ1	SLMODR1Y
FTM-7250DR	SLUSBRJ1	SLCABRJ1	SLMODR1Y
VX-1R	SLUSBHTY	SLCABHTY	SLMODHT
VX-2R	SLUSBHTY	SLCABHTY	SLMODHT
VX-3R	SLUSBHTY	SLCABHTY	SLMODHT
VX-5R	SLUSBHTY	SLCABHTY	SLMODHT
VX-6R	SLUSBVXY	SLCABVXY	SLMODHT
VX-7R	SLUSBVXY	SLCABVXY	SLMODHT
VX-110	SLUSBHTY	SLCABHTY	SLMODHT

YAESU (continued)

Radio	Signalink USB	Radio Cable Only	Jumper Module
VX-120	SLUSBVXY	SLCABVXY	SLMODHT
VX-150	SLUSBHTY	SLCABHTY	SLMODHT
VX-160	SLUSBHTY	SLCABHTY	SLMODHT
VX-170	SLUSBVXY	SLCABVXY	SLMODHT
VX-177	SLUSBVXY	SLCABVXY	SLMODHT
VX-230	SLUSBHTY	SLCABHTY	SLMODHT
VX-350	SLUSBHTY	SLCABHTY	SLMODHT
VX-410	SLUSBHTY	SLCABHTY	SLMODHT
VX-420	SLUSBHTY	SLCABHTY	SLMODHT
VX-420A	SLUSBHTY	SLCABHTY	SLMODHT
VX-8R	SLUSBHTY ⁶	SLCABHTY ⁶	SLMODHT
VX-8DR	SLUSBHTY ⁶	SLCABHTY ⁶	SLMODHT
VX-8RE	SLUSBHTY ⁶	SLCABHTY ⁶	SLMODHT
VX-8GR	SLUSBHTY	SLCABHTY	SLMODHT
VX-1700	SLUSB6PM	SLCAB6PM	SLMOD6PM
VX-2100	SLUSBRJ4	SLCABRJ4	SLMODR4Y
VX-2200	SLUSBRJ4	SLCABRJ4	SLMODR4Y

Notes:

1. This jack does NOT mute the microphone when it is in use. If you attach the Signalink to this jack then you will either need to turn down the radio's Mic Gain control, or disconnect the microphone to avoid having a ōhotō mic.
2. This jack is for HF use only. For VHF or UHF operation, you will need to attach the Signalink to a different jack on the radio.
3. This jack is for FM use only. It does NOT support USB/LSB operation.
4. Requires Yaesu's CT-164 adapter to convert from the radio's 10-pin mini-DIN connector to a standard 6-pin mini-DIN. This adapter should be available from any authorized Yaesu dealer.
5. Requires Yaesu's CT-141 adapter to convert from the radio's 8-pin mini-DIN connector to a standard 6-pin mini-DIN. This adapter should be available from any authorized Yaesu dealer.
6. Requires Yaesu's CT-131 adapter. This adapter should be available from any authorized Yaesu dealer.